Quick Start Guide

Using Your RoboVac

OFF   ON

1   **2**

Remove the sticker next to the power switch, and the foam blocks beside the bumper before use.

3   **4**

3ft/1m
3ft/1m   6ft/2m

If you cannot remove the objects surrounding the Charging Base, check whether RoboVac can return without assistance; if not, contact eufy customer service for help.

- Always keep the Charging Base plugged in, otherwise RoboVac will not automatically return.
- When the Charging Base is connected to AC power, the LED indicator on the Charging Base is SOLID WHITE.

5

Fully charge RoboVac before use. The LED indicator on RoboVac pulses orange while charging, and is solid blue when fully charged.

6

Download the EufyHome app and follow the in-app instructions to complete the Wi-Fi connection. You then will be able to control RoboVac via this app. Refer to the Owner's Manual for details.

EufyHome   EufyHome

Download on the App Store

GET IT ON Google Play

7

Important Tips

When using for the first time, follow RoboVac to observe and resolve any problems that may occur.

A Remove power cords and small objects from the floor that may entangle RoboVac. Use the supplied cable ties to organize your wires and power cords.

B Fold tasseled edges of area rugs underneath to prevent tangling RoboVac. Avoid cleaning very dark-colored high-pile rugs or rugs thicker than 1.02 in/26 mm as they may cause RoboVac to malfunction.

C It is strongly recommended to place boundary strips (sold separately) in front of fireplaces and certain areas (i.e. air vents) that may cause damage to RoboVac if entered.

D Keep RoboVac away from wet areas during cleaning.

E RoboVac may climb on top of objects less than 0.67 in/17 mm in height. Remove these objects if possible.

F Anti-drop sensors will prevent RoboVac from tumbling downstairs and steep drops in most cases. Sensors are less effective if dirty or used on carpeted/reflective/very dark-colored floors. It is recommended to place physical barriers to block off areas where RoboVac may fall.